



HUBBARD CRALL HANGER ADAPTER SLEEVE SETUP SHEET

Hubbard Crall Hanger Adapter Sleeves are available in two different styles to handle any rod hanging need.

Adapter Sleeves for Standard Rod Hangers

Rod Size	1/2"	5/8"	3/4"	7/8"	1"
Adapter Sleeves on every finger	●				
Adapter Sleeves on every other finger		●			
No Adapter Sleeves			●	●	●

Special S-S Adapter Sleeves for Steel and Fiberglass Rod Hangers

Rod Size	5/8"	3/4"	7/8"	1"	1-1/8"	1.25"
S-S Adapter Sleeves on every finger	●					
S-S Adapter Sleeves on every other finger		●				
No Adapter Sleeves			●	●	●	●